

# Right Connections

**towbar wiring kits for the uk**

Berlingo	05/2008 >>	10/2011
Berlingo Multispace	05/2008 >>	10/2011
Dispatch / Dispatch Van	01/2007 >>	06/2016
Scudo / Scudo Van	01/2007 >>	06/2016
Expert / Expert Van	02/2007 >>	06/2016
Partner Van	05/2008 >>	10/2011
Partner Tepee	05/2008 >>	10/2011
Proace	04/2013 >>	01/2016

**13-pin / ISO 11446**

**Electrical Installation  
Kit For Tow Bar**

Part number

**TO26513M**

TO26513M

**CITROEN / FIAT / PEUGEOT / TOYOTA**

