

Right Connections

13-pin / ISO 11446

Electrical Installation
Kit For Tow Bar


towbar wiring kits for the uk

Citroen C3 Aircross	10/2017 >>
Citroen C4	01/2021 >>
Citroen C4 X (C43)	10/2022 >>
Citroen ë-C4	01/2021 >>
Citroen ë-C4 X (C43EV)	10/2022 >>
Citroen Berlingo M / XL	10/2018 >>
Citroen ë-Berlingo	12/2021 >>
DS 3 / DS 3 Cabriolet	07/2018 >>
DS 3 Crossback	04/2019 >>
DS 3 Crossback E-Tense	01/2020 >>
DS 9 Saloon	05/2021 >>
Fiat Doblo	07/2022 >>
Fiat E-Doblo	07/2022 >>
Jeep Avenger	01/2023 >>
Vauxhall Crossland X	06/2017 >> 12/2020
Vauxhall Crossland	01/2021 >>
Vauxhall Combo (E) Life/Life XL	10/2018 >>
Vauxhall Combo (E) Cargo	10/2018 >>

Vauxhall Combo-e Cargo	12/2021 >>
Vauxhall Corsa-e	02/2020 >>
Vauxhall Corsa (F)	11/2019 >>
Vauxhall Mokka (B) / Mokka-e	03/2021 >>
Peugeot 208 II	10/2019 >>
Peugeot 2008 II	01/2020 >>
Peugeot e-208	11/2019 >>
Peugeot e-2008	04/2020 >>
Peugeot Rifter L1 / L2	10/2018 >>
Peugeot Partner L1 / L2	11/2018 >>
Peugeot e-Rifter	02/2022 >>
Peugeot e-Partner	02/2022 >>
Toyota Proace City L1 / L2	12/2019 >>
Toyota Proace City Verso L1 / L2	12/2019 >>

Part number

VA-010-13M



**CITROEN/DS/FIAT/JEEP
VAUXHALL/PEUGEOT/TOYOTA**

VA-010-13M