

# Right Connections

**towbar wiring kits for the uk**

7-pin / ISO 1724

Electrical Installation  
Kit For Tow Bar

A3 3-door 05/03 >> 07/12	Caddy III all models 02/04 >> 2011	Jetta 08/05 >> 12/10
A3 Sportback 09/04 >> 01/13	Caddy III Life 07/04 >> 10/20	Jetta 01/11 >>
A3 Cabriolet 03/08 >> 02/14	Caddy III Maxi 01/08 >> 10/20	Passat Alltrack 02/12 >> 10/14
Q3 10/11 10/11 >>	Caddy III Cross 06/13 >> 10/20	Passat CC 06/08 >>
Alhambra 09/10 >>	Caddy IV all models 06/15 >> 10/20	Passat Saloon 03/05 >> 10/10
Altea 06/04 >>	Caddy IV Life 06/15 >> 10/20	Passat Saloon 11/10 >> 10/14
Altea Freetrack 09/07 >>	Caddy IV Maxi 06/15 >> 10/20	Passat Estate 08/05 >> 10/10
Altea XL 10/06 >>	Caddy IV Cross 06/15 >> 10/20	Passat Estate 11/10 >> 10/14
Leon 09/05 >> 10/12	CC 01/12 >>	Tiguan I 11/07 >> 04/16
Toledo 12/04 >> 08/09	Eos 05/06 >>	Touran I 03/03 >> 08/15
	Golf Plus 02/05 >>	Sharan 09/10 >>
	Golf V 10/03 >>	
Octavia II Estate 01/05 >> 05/13	Golf V Estate 06/07 >>	
Octavia II Saloon 06/04 >> 01/13	Golf VI 10/08 >>	
Octavia II Scout 03/07 >> 07/14	Golf VI Estate 09/09 >>	
Superb II Estate 01/10 >> 08/15	Golf VI Cabriolet 06/11 >>	
Superb II Saloon 07/08 >> 05/15		
Yeti 09/09 >>		

Part number

**VW19507M**

VW19507M

**AUDI / SEAT / SKODA / VOLKSWAGEN**

