




Right Connections


towbar wiring kits for the uk

FIAT/ JEEP

500X 05/2015 >>
Renegade 02/2015 >>
Renegade Hybrid 08/2020 >>

Part No: FI-048-13M

Electric wiring kit for towbars / 13-pin / 12 Volt / ISO 11446 Fitting instructions



IMPORTANT!

This electric kit has to be installed by a professional workshop or a suitable qualified person.

The installation instructions must have been read and fully understood before the start of any installation. Please contact your wiring kit provider or the hotline shown in the footer should you need assistance!

Make sure the vehicle is approved/homologated by the manufacturer to tow a trailer!

Also please check that there is a definite compatibility between this vehicle and the electric kit!

Following the installation of the electric kit, the fitting instructions should be kept together with the vehicle service document and vehicle handbook. The fitting instructions contain important information relating to the use and function of the towing kit as well as for any diagnostic or activation process, that might have to be repeated in the future (e.g. after the performance of a vehicle software update).

All warranty claims will be forfeited if the electric kit or components contained therein are used incorrectly or modified. If a towing socket adaptor has been used to connect to the trailer or bike rack, this must be removed from the trailer socket once the trailer or bike rack has been disconnected.

If the trailer or bike rack is not equipped with a rear fog lamp, depending on the towing vehicle type, the correct function of the towing kit cannot be guaranteed. In such cases, a rear fog lamp should be retro fitted.

This towing electric kit will not be covered under warranty if any technical or electrical modifications or software updates have been performed by the vehicle manufacturer after the initial commissioning of the kit. That applies especially to modifications or updates which may cause malfunctions in the trailer socket or any other part of the trailer electrical equipment!

Depending on the type of trailer module used in this electric kit, diagnostic interrogation with the vehicle's electrical system may be limited or will not function. The error memory inside the trailer module may not be able to be accessed by vehicle manufacturers diagnostic system.

Error logs relating to the trailer electrical equipment, that may be generated in the vehicle manufacturers diagnostic system as a result of a test procedure, may be due to the incorrect installation of the towing electric kit or the false activation of the trailer module.

We always recommend whenever possible, the following troubleshooting process:

→ **An analysis of the vehicle's error memory and possibly clearing of all faults before the start of the installation!**


→ **Try disconnecting the trailer module from the towing harness and re-start the fault clearing process!**

→ **If in doubt, limit the time for troubleshooting to a max of 0,5 hours and call our Technical Support Team!**

Please follow our instructions carefully and always test the towing electrics using a true lighting board or a specifically designed bulb tester. If an LED tester is used, ensure it is equipped with correct load resistors or malfunctions will occur!


This instruction is subject to changes and we reserve the right to make changes to design, colour etc.

All of the data and illustrations may not be an exact representation but the text contained in this instruction must be observed!



M

M1



5x

G I

L2

L1

C


B1

F

R


* Optional

Pag. 21



D

E



C


B1

F

R

* Optional

Pag. 21



3x

3x

3x

2x

1x

4x

1x

10x

B


1x

1x

1x

1x

FIAT 500X / JEEP Renegade



32-36

9, 17-20, 23

10-16

38-40



21-22, 24-31

SYMBOL EXPLANATION

	Left (58-L) respectively Right (58-R) tail light
54	Stop light (54) / high mounted, third stop light (54)
	Turn signal indicator left
	Turn signal indicator right
	Rear fog light(s)
	Reversing light(s)
	Permanent power supply / 13pin socket, chamber 9
	Charging wire for trailer battery / 13pin socket, chamber 10
	Trailer / trailer recognition
B+ / 30	Permanent current power supply
	Ground or Earth (31)
	Ground connection battery terminal lug
	Positive connection battery terminal lug


	Cigarette lighter / accessory socket
	Loudspeaker / buzzer
	Park Distance Control
	Switch / source of function
	Connect together
	Disconnect
	Look at / See further information
	Look carefully at selected area
	Present / Occupied / OK
	Not present / Not occupied / Not OK
	Acoustic indication
	Attention / important advice
	Fuse / fuse capacity 20 Ampère

TOOLS



ATTENTION!

The vehicle's cooling capacity may have to be increased when retrofitting a trailer coupling!
You must observe the manufacturer's instructions!!



Note: It may be necessary to check if this vehicle has a stored radio code before disconnecting the battery!




ATTENTION!

In order to avoid mal-functions and damage to the vehicle's electrical system the earth terminal must be disconnected from the vehicle's battery before starting work!


Both the trailer module and the vehicle's control unit for the electrical system can be damaged during work on the data bus connections if the battery is not disconnected!

Please pay attention to the manufacturer's instructions when disconnecting and reconnecting the vehicle's battery!


500X




500X



500X




Renegade




5

Renegade




6

Renegade




7

500X / Renegade







8

Jeep Renegade




Fiat 500 X




SEAL WITH SILICONE.

9




Option 1



Option 2



10




11

SOCKET CONNECTION





Page 23

12



13


Option 1




14

Option 2


1




2



3




4




15

Option 2


1




2



3




4




16


1





2




3




4




5




6




7



8





9





17

500X





18

Renegade




19


500X



20





500X




21





500X



22




Renegade



23




Renegade

cut to length !!




24

Renegade



25

Vehicles with PDC-System







Vehicles without PDC-System





26


500X / Renegade




27




1




2





3



4





Renegade




29

Renegade




1




2

30



500X / Renegade



31




32




33

CAN bus connection




BCM
(Body control Module)



SGW
(Security Gate Way)


SGW

 Security Gate Way


**8-pole
BK**


Option 1

SGW
fitted
verbaut
équipé



Option 2

SGW
not fitted
nicht verbaut
non équipé



Option 3


MY 2022 >>




Option 1

Without Security Gate Way

With Security Gate Way
Mit Security Gate Way



Security Gate Way




Important!
Please note
informations in
picture 1!

Wichtig!
Unbedingt Hinweise
aus Bild 1 beachten!

CAN-Data Wire



PIN3
PIN8



8-pole
BK




CAN High

Pin 3

CAN Low

Pin 8






BN
GN

R



Option 2

Without Security Gate Way

**OBD****CAN-Data Wire**

PIN3

PIN11

**CAN High**Pin 3
Blue or Grey**CAN Low**Pin 11
WhiteImportant!
Please note
informations in
picture 1!

Black

OBD
PIN 3

Yellow


OBD
PIN 11Black
Yellow

C


Option 3

With Security Gate Way
Mit Security Gate Way

MY 2022 >>




BCM Security Gate Way











Important!
Please note
informations in
picture 1!

Wichtig!
Unbedingt Hinweise
aus Bild 1 beachten!




CAN-Data Wire





! Important!
Please do not mount the fuse tap and its wiring output in the other direction!


Optional



Extension kit
UV-003-ZZ3




41



42



Optional




Trailer Simulator for 7- and
13-pin Sockets

43

Functional test




44





45

Optional


Adapter socket



46



47



48