

**Right**  
**Connections**

towbar wiring kits for the uk

**SP572ZZC**

**CAN Bus  
Trailer Module 12 V**

>PA66-GF30<

**E4 10R - 05 3284**

<u>54</u>	<u>15</u>	<u>54in</u>	<u>CANL</u>	<u>CANH</u>	<u>54G</u>	<u>BU</u>
<u>30</u>	<u>L</u>	<u>58L</u>	<u>31</u>	<u>R</u>	<u>58R</u>	<u>30</u>

**5F008V0101SW7870**

Made in Germany



RoHS

**Right**  
**Connections**

towbar wiring kits for the uk

**SP572ZZC**

**CAN Bus  
Trailer Module 12 V**

>PA66-GF30<

**E4 10R - 05 3284**

<u>54</u>	<u>15</u>	<u>54in</u>	<u>CANL</u>	<u>CANH</u>	<u>54G</u>	<u>BU</u>
<u>30</u>	<u>L</u>	<u>58L</u>	<u>31</u>	<u>R</u>	<u>58R</u>	<u>30</u>

**5F008V0101SW7870**

Made in Germany



RoHS